

New Rock Technologies, Inc.

MX100G SIP-ISDN Gateway Series

User Manual

MX100G

MX100G-S

Website: <http://www.newrocktech.com>

Email: gs@newrocktech.com

Document Version: 202008



Amendent Records

Document Rev.02 (August, 2020)

This document is applicable for V182.

Document Rev. 01(June, 2017)

This document is applicable for V115.

Contents

Amendent Records	2
Contents	3
Contents of Figure	5
Contents of Table	7
1 Overview	1-1
1.1 Product Introduction.....	1-1
1.2 Features.....	1-1
1.3 Equipment Structure	1-2
1.3.1 Front & Back Panel.....	1-2
1.3.2 CON Port.....	1-5
1.3.3 Specifications	1-6
2 Installation Preparation	2-8
2.1 Installation Precautions.....	2-8
2.2 Site Requirements	2-8
2.2.1 Temperature and Humidity	2-8
2.2.2 Cleanliness	2-8
2.2.3 Power Supplier	2-9
2.2.4 Grounding.....	2-9
2.2.5 Electromagnetic Environment.....	2-9
2.2.6 Other Facilities.....	2-9
2.3 Opening Inspection	2-10
3 Installation	3-1
3.1 Tools and Meters	3-1
3.2 Rack Mounting.....	3-1
3.2.1 Attaching the Brackets.....	3-1
3.2.2 Mounting the Gateway.....	3-1
3.3 Installing Cables.....	3-2
3.3.1 Connecting Console Port.....	3-2
3.3.2 Connecting the Ethernet Cable.....	3-3
3.3.3 Connecting the T1/E1 Cable.....	3-3
3.3.4 Connecting the Grounding Cable	3-4
3.3.5 Connecting the Power Cord.....	3-4
3.3.6 Verifying Installation	3-5
4 Powering up the Gateway	4-1
4.1 Verification before Power-up.....	4-1
4.1.1 Checking Appearance	4-1
4.1.2 Checking Power Supply.....	4-1
4.2 Powering up the Gateway	4-1

5 Parameter Setting	5-1
5.1 Login	5-1
5.2 Buttons Used on Gateway Management Interface.....	5-2
5.3 Basic Configuration.....	5-2
5.3.1 Network Configuration	5-2
5.3.2 STUN (RFC3489)	5-3
5.3.3 VLAN	5-5
5.3.4 System Configuration	5-5
5.3.5 SIP Configuration	5-7
5.3.6 SIP Trunk.....	5-8
5.3.7 ISDN Configuration.....	5-9
5.3.8 FoIP	5-10
5.4 ISDN	5-12
5.5 Routing	5-16
5.5.1 Digit Map	5-16
5.5.2 Routing Table	5-18
5.5.3 Application Examples of Routing Table	5-22
5.6 Advanced Configurations.....	5-23
5.6.1 System.....	5-23
5.6.2 Media Stream	5-25
5.6.3 SIP Configuration	5-27
5.6.4 RADIUS	5-29
5.6.5 Tones.....	5-29
5.6.6 System time.....	5-31
5.7 Security.....	5-33
5.7.1 Access Security	5-33
5.7.2 Access list.....	5-34
5.7.3 Voice Security.....	5-35
5.7.4 Encryption.....	5-36
5.8 Call Status	5-37
5.9 Log Management.....	5-37
5.9.1 System Status	5-37
5.9.2 Call Message.....	5-39
5.9.3 ISDN Status.....	5-39
5.9.4 System Startup	5-41
5.9.5 Manage Log.....	5-41
5.10 System Tool.....	5-42
5.10.1 Configuration Maintenance.....	5-42
5.10.2 Upgrade.....	5-42
5.10.3 Restore Factory Settings	5-44
5.10.4 IP Capture	5-44
5.10.5 Reboot.....	5-44
5.11 Version Information.....	5-44
5.12 Logout.....	5-45

Contents of Figure

Figure 1-1 Front Panel	1-2
Figure 1-2 Back Panel (AC)	1-4
Figure 1-3 Back Panel (DC).....	1-5
Figure 1-3 RJ45 to RS232 serial cable	1-6
Figure 1-4 USB to RS232 converter cable.....	1-6
Figure 3-1 Installation of MX100G Series L-shape Brackets	3-1
Figure 3-2 Mount MX100G to Rack	3-2
Figure 3-3 Cable of Connecting MX100G CON	3-3
Figure 3-4 Connecting the T1/E1Cable.....	3-4
Figure 5-1 Login Interface for MX100G Gateway Configuration	5-1
Figure 5-2 Network Configuration Interface	5-2
Figure 5-3 STUN configuration interface.....	5-4
Figure 5-4 VLAN Configuration Interface	5-5
Figure 5-5 System Configuration Interface	5-6
Figure 5-6 SIP Configuration Interface.....	5-7
Figure 5-7 SIP Trunk Settings Interface.....	5-9
Figure 5-8 ISDN Configuration Interface.....	5-10
Figure 5-9 FoIP Configuration Interface.....	5-11
Figure 5-10 ISDN Configuration Interface.....	5-13
Figure 5-11 Configuration Interface for Digit Map	5-17
Figure 5-12 Configuration Interface for Routing Table	5-19
Figure 5-13 System Advanced Configuraiton Interface.....	5-24
Figure 5-14 Media Stream Configuration Interface	5-26
Figure 5-15 SIP Related Configuration Interface	5-27
Figure 5-16 RADIUSConfiguration Interface.....	5-29
Figure 5-17 Tones Configuration Interface	5-30
Figure 5-18 Clock Service Interface.....	5-31
Figure 5-19 Access Configuration Interface	5-33
Figure 5-20 Access list configuration Interface	5-35
Figure 5-21 Voice Security Configuration Interface	5-35
Figure 5-22 Encryption Configuration Interface	5-36
Figure 5-23 ISDN Status Interface.....	5-37
Figure 5-24 System Status Interface.....	5-38
Figure 5-25 Call Message Interface	5-39
Figure 5-26 ISDN Status Interface	5-40
Figure 5-27 System Startup Interface	5-41
Figure 5-28 Manage Log Interface.....	5-41
Figure 5-29 Configuration Importing or Exporting Interface	5-42
Figure 5-30 Upgrade Interface	5-43
Figure 5-31 Upgrading interface by .img file	5-43
Figure 5-32 Upgrade Interface	5-43
Figure 5-33 Ethereal interface	5-44
Figure 5-34 Version Information Interface.....	5-45

Contents of Table

Table 1-1 Front Panel	1-3
Table 1-2 Indicators	1-3
Table 1-3 Pinouts of Ethernet Ports	1-4
Table 1-4 Pinouts of T1/E1 Module.....	1-4
Table 1-5 Description of Back Panel.....	1-4
Table 1-6 Description of Back Panel.....	1-5
Table 1-7 Standard Table for Lead Wire of Pin at Configuration Port (CON).....	1-5
Table 1-8 Attributes of CON Port	1-6
Table 1-9 Specifications.....	1-6
Table 2-1 Standard Configuration	2-10
Table 5-1 Network Configuration Interface	5-3
Table 5-2 STUN parameters	5-4
Table 5-3 VLAN Configuration Parameters.....	5-5
Table 5-4 System Configuration Parameters	5-6
Table 5-5 Codec Methods Supported by Gateway	5-7
Table 5-6 SIP Configuration Parameters	5-7
Table 5-7 SIP Trunk Parameters	5-9
Table 5-8 ISDN Configuration Parameters	5-10
Table 5-9 FoIP Configuration Parameters	5-11
Table 5-10 ISDN Configuration Parameters	5-13
Table 5-11 Operated Numbers and Translation Rules.....	5-15
Table 5-12 Description of Digit map.....	5-17
Table 5-13 Routing Table Format	5-20
Table 5-14 Number Transformations	5-20
Table 5-15 Routing Destination	5-22
Table 5-16 Advanced System Configuration Parameters	5-24
Table 5-17 Media Stream Configuration Parameters.....	5-26
Table 5-18 SIP Related Configuration Parameter.....	5-27
Table 5-19 RADIUS Configuration Parameter	5-29
Table 5-20 Tones Configuration Parameters	5-30
Table 5-21 Clock Service Parameters	5-32
Table 5-22 Access security setting parameters	5-34
Table 5-23 Encryption Configuration Parameters	5-36
Table 5-24 Status Parameters	5-37
Table 5-25 System Status Parameters	5-38
Table 5-26 ISDN Status Parameters.....	5-40
Table 5-27 Manage Log Parameters	5-41

1 Overview

1.1 Product Introduction

The MX100G and MX100G-S SIP-ISDN trunking gateway (hereinafter the MX100G) is a VoIP product series developed by New Rock Technologies Inc. It uses the SIP and T1/E1 interfaces for the inter-conversion of IP packets and PCM signals, allowing the interworking of the IP-based new-generation voice network to legacy Public Switched Telephone Network (PSTN), and the private branch exchange (PBX) of an enterprise.

As a carrier-class VoIP gateway, the MX100G is designed under the requirements of telecom operators, integrators, value-added service providers as well as large and medium-sized enterprises for VoIP services. The MX100G has distinctive advantages over other similar products in terms of performance, system reliability, compatibility and cost performance. In addition, the MX100G has efficient software/hardware architecture and powerful DSP processing capabilities, ensuring the realization of major functions (including the conversion between PCM signals and IP packets, G.711 or G.729A encoding and decoding of voice signal, and echo cancellation, etc.) even under full load conditions.

By supporting the ISDN PRI signalling, the MX100G can control its calls with the PSTN or PBX. The call control between the MX100G and media gateway controller (softswitch) is carried out through Session Initiation Protocol (SIP). By now, the MX100G has successfully passed the interoperability test with various popular softswitch platforms and IP PBX products.

1.2 Features

The MX100G has the following characteristics:

High performance

The DSP chip with powerful voice processing used by the MX100G is developed by the TI Company. Its DSP daughter card ensures a 6000 MIPS processing capability for each gateway, enabling the MX100G to provide functions of voice signal processing (G.711, G.729A, and G.723.1), echo cancellation, and fax relay (T.38) under full load conditions (120 calls).

High security

To ensure security, the MX100G-S supports SSH and HTTPS for remote access, and provides functions including signaling and media stream encryption, automatic password strength test, brute-force password cracking prevention, cipher text data storage, access whitelist, and system log backup.

High reliability

The MX100G-S provides high-availability features including 1+1 redundancy of Ethernet ports and AC/DC power supplies (optional), and SIP registration failover.

Remote Management and Maintainability

The New Rock Cloud client inside the MX100G-S allows the MX100G-S located behind an enterprise NAT or firewall to be accessed across Internet securely. Real-time monitoring, alarm notification, remote packet capture and software upgrades can be performed with the New Rock Network Management System or third-party element management systems with TR-069.

Low cost and high reward

How to reduce cost and investment risk is one of the major challenges a user faces when choosing an IP-based new generation of voice device. The MX100G helps reducing users' cost by increasing new functions and applications to follow the ongoing evolution of VoIP technologies. This can be realized through New Rock's software upgrade free of charge policy within the life cycle of the MX100G.

In support of multiple protocols

The MX100G supports different kinds of protocols including Session Initiation Protocol (SIP), Real-time Transport Protocol (RTP), Trivial File Transfer Protocol (TFTP), File Transfer Protocol (FTP), Hypertext Transfer Protocol (HTTP), Session Traversal Utilities for NAT (STUN), Also, the MX100G supports different technologies including ISDN PRI signalling, G.711, G.729A, or G.723.1 encoding and decoding, G.168 echo cancellation, Dual-Tone Multi-frequency (DTMF) message transmission (RFC 2833), and fax relay (T.38).

High interoperability

By now, the MX100G has successfully passed the interoperability test with various softswitch platforms and IP PBX products.

1.3 Equipment Structure

1.3.1 Front & Back Panel

Figure 1-1 Front Panel



Table 1-1 Front Panel

#	Mark	Description
①	RST	Pressing the RST button for less than three seconds: no action will be taken. Pressing the RST button for more than three seconds: the factory settings will be restored.
②	PWR	Indicators for power supply, system status and alarm, respectively.
③	STU	
④	ALM	
⑤	CON	A configuration interface.
⑥	ETH	Specifies an RJ45 module interface. Interfaces ETH1 and ETH2 share the same IP address for allowing access to the external network. Dual-LAN redundancy is supported.
⑦	AUX	An RJ45 interface. Interfaces AUX1 and AUX2 share the same IP address for local management and configuration.
⑧	T1/E1	An RJ45 interface, in support of 1 T1/E1, 2 T1/E1, and 4 T1/E1. Each T1 interface supports the maximum 24 voice channels; each E1 interface supports the maximum 30 voice channels with ISDN PRI signalling.
⑨	SD	A SD card socket.

Table 1-2 Indicators

Mark	Function	Status	Description
PWR (red, green)	Power Indication	Steady green	The power supply is working.
		Off	No power supply.
		Steady red	The power supply is abnormal.
STU (red, green)	Status Indication	Off	The device is locked.
		Blinking red	System is in a diagnostic mode and you can execute limited operation (e.g. Log in to system through Telnet)
		Steady Red	The device is starting.
		Blinking green	System is operating normally
ALM (red, green)	Alarm Indication	Steady green	No alarms
		Blinking red	Device startup failure
		Steady red	Network failure or app exited
ETH/ AUX	Interface state indicator	Steady green (right side)	The transmit speed is 1000M bit/s.
		Off (right side)	The transmit speed is 10M bit/s or 100M bit/s.
		Steady green (left side)	The link has been established but no service traffic is transmitted.
		Blinking green (left side)	Service traffic is being transmitted on the link.
		Off (left side)	The link is not established.
T1/E1	Interface state	Steady green	The connection works normally.

Mark	Function	Status	Description
(red, green)	indicator	Blinking red	A remote alarm is generated.
		Steady red	A local alarm is generated.
		Off	No connection is established.

Table 1-3 Pinouts of Ethernet Ports

RJ45 Pin-out	1	2	3	6
Description	TX+	TX-	RX+	RX-

Table 1-4 Pinouts of T1/E1 Module

RJ45 Pin-out	1	2	3	4	5	6	7	8
Description	RX Ring	RX Tip	NC	TX Ring	TX Tip	NC	NC	NC

Figure 1-2 Back Panel (AC)



Table 1-5 Description of Back Panel

#	Description
① 	AC power socket, 100-240 VAC voltage input.
② 	Ground pole.

Figure 1-3 Back Panel (DC)



Table 1-6 Description of Back Panel

#	Description
① 	DC power socket, -36 to -72 VDC voltage input.
② 	Ground pole.

1.3.2 CON Port

The MX100G provides one configuration interface (CON) of RJ45 interface for local management and debugging.

Table 1-7 Standard Table for Lead Wire of Pin at Configuration Port (CON)

Pin number of RJ45 plug	1	2	3	4	5	6	7	8
Description	NC	NC	TXD	GND	GND	RXD	NC	NC
Pairing connection with DB9 female plug			2		5	3		
Pairing connection with DB25 male plug			3		7	2		

The configured interface is connected to the RS232 port on the PC, allowing the PC to establish the connection with the MX100G by configuring a terminal emulator. The configured interface of MX100G is in a 3-wire configuration: one TXD (data transmission terminal), one RXD (data reception terminal), and one GND (ground terminal).

Please use a RJ45 to RS232 serial cable as shown in Figure 1-3 for connecting the CON port on MX100G side and the RS232 port on PC side. If the connection is established between MX100G and the mobile PC with no RS232 ports, please use the cable together with USB to RS232 converter cable as shown in Figure 1-4.

Figure 1-3 RJ45 to RS232 serial cable



Figure 1-4 USB to RS232 converter cable



Table 1-8 Attributes of CON Port

Attributes	Description
Connector	RJ45
Interface count	1
Interface standard	RS232
Baud rate	115200
Data bit	8
Parity	No
Stop bit	1
Traffic control	No

1.3.3 Specifications

Table 1-9 Specifications

Item	Description
Basic	
Ethernet	RJ45, 4×10/100/1000M Base-T, self-adaptive
E1/T1Interface	4, 120 simultaneous VoIP calls
SD Interface	1
CON Interface	RJ45
System Memory	256MB
System Flash	32MB
Processor	TI AM3352
DSP	TI C5509
Single/Dual AC power supplies	~100 to 240V, 50/60Hz, 1A
Single/Dual DC power supplies	-36 to -72 VDC, 2.5A
Power Consumption	18 W (Max)
Size (H×W×D)	44×440×300 mm,1U formfactor
Weight	net weight:3 kg gross weight(with box):5 kg
Environment Requirements	
Operating Environment	0 to 40oC, Non-Condensing Humidity 10 to 95%
Storage Environment	-10 to 60oC, Non-Condensing Humidity 10 to 95%

2 Installation Preparation

For avoidance of personal injury and device damage, please read this chapter carefully before installation.

2.1 Installation Precautions

For your safety, please follow the precautions when MX100G is installed and used.

- Keep the site far from the heat and humidity
- Take precautions with use of high-voltage electricity
- Please let the experienced or trained operator to install and maintain MX100G
- Wear static discharge wrist strap
- Ensure the proper electric ground of installed equipment
- Properly connect the power cable to MX100G
- Do not plug the power cable when in use
- UPS is advised

2.2 Site Requirements

2.2.1 Temperature and Humidity

Check the temperature and humidity of equipment room. To ensure the normal operation and long service life of the gateway, the temperature and humidity in the room should be kept at the proper range.

The humidity in the equipment room should be kept between 10% and 90% (non-condensing). Abnormal humidity condition may cause problems to the gateway:

- Long term high humidity may lead to bad insulation and even cause electricity leakage, mechanical property change and corrosion.
- Low humidity is likely to leave captive screws to loose due to static electricity built up and the insulation washer shrunk.

The temperature in the equipment room should be kept between 0oC and 40oC. Abnormal temperature condition may cause problems to the gateway:

- High temperature acceralets aging of electrical parts and insulation materials.
- Low temperature, however, may destabilize the operation of gateway.

2.2.2 Cleanliness

Dust is very harmful to the safe operation of the gateway. Dust that is adsorbed by static electricity acts as insulator, which not only affects the service life of the gateway but also leads to communication failure. Therefore, the room for the gateway must be kept clean.

To ensure adequate ventilation to keep the gateway from overheating, there should be adequate clearance for the air intake and the air exhaust vents. Keep at least 6 cm clearance at the left and right side of the chassis where the air intake is and at least 15 cm clearance at the rear of the chassis where the exhaust vents located.

The rack for MX100G should have a good ventilation system.

2.2.3 Power Supplier

Check the power supply system against the electrical specification of the gateway.

2.2.4 Grounding

For AC power supply system

To maintain good voice quality, proper grounding of the AC supply is critical to minimize the noise from the AC interference. Therefore, the following conditions must be ensured:

- The AC power outlet has a protection ground contact.
- The ground contact of AC supplier must be grounded properly.
- Avoid sharing the multi-outlet power strip with other devices that may generate electrical interference.

MX100G is chassis based with ground tab.

In a site that can provide ground for the chassis, the ground tab at the rear panel of chassis for MX100G must be properly grounded.

For DC power supply system

The DC power working ground (the positive pole of the -48 V DC power supply or negative pole of the 24 V DC power supply) of the communications site should be connected with the indoor collective grounding cables nearby. The grounding cables should meet the requirement for the maximum load of the equipment.

The power supply equipment of the communications site should be connected with from the collective ground cable in the communications building (or from the protection grounding bar of the equipment) to the DC working ground cable.

2.2.5 Electromagnetic Environment

Any possible interference source, wherever it is from, impacts the gateway negatively. To resist the interference, make sure that:

- Keeping the gateway far from radio transmitting station, radar station, and high-frequency devices. Use electromagnetic shielding when necessary.
- The gateway is capable for secondary lightning protection on wires and cables that connected to outside buildings. The site must provide the primary lightning protection.
- The power supply system should be used independently as much as possible and effective measures of preventing electric grid from interference should be adopted.
- Ensure a good power grounding effect of equipment or add a lightning protector.

2.2.6 Other Facilities

- **Rack/Workbench**

MX100G is designed to be installed in a standard 19-inch rack, which should provide adequate air-flow to cool down the gateway, and should be firm enough to support the weight of the gateway. It is also recommended the rack is earth grounded properly.

- **PSTN Line**

If the gateway is equipped with T1/E1 interface, be sure to subscribe PSTN lines from local telephone company and activate the lines prior to the installation.

- **IP Network**

The gateway is connected to IP network through its 10/100/1000 base-T Ethernet port and communicate with other equipments through the network. Inspect IP network on the site, including router, switch, cable wiring and etc, and make sure they are ready for the gateway.

- **AC Power Outlets**

The gateway needs AC power supply, and sometimes the power is provided through a power strip with extension cord. Verify that each socket outlet on the power strip is equipped with protective earth contact and the protective action is not negated by using extension power cord.

2.3 Opening Inspection

After the completion of installation preparation, you should open the box for inspection. Make sure the gateway and all in-box accessories match the description below.

An MX100G with basic configuration should include components as shown in following table.

Table 2-1 Standard Configuration

Description	Quantity	Unit
MX100G	1	Set
Rack Mounting Kits	1	Set
T1/E1 Cable	1/2/4	Set
Power Cord (AC or DC)	1 or 2 Note: 2 for dual power supplies	Set
Grounding Cable	1	Set



Note

The package list is only for reference. Changes may be made without notification. The detailed inclusions are on the shipping list enclosed in the device package. Please contact your supplier if you have any question.

3 Installation

3.1 Tools and Meters

- Screwdriver
- Antistatic wrist strap
- Ethernet and console port cables
- Power cable
- Terminals (a PC running terminal program can be used)
- Universal electric meter
- Multimeter

3.2 Rack Mounting

The MX100G series chassis are designed to be mounted on a standard 19-inch rack with 1U height.

3.2.1 Attaching the Brackets

Place the MX100G series chassis on the workbench, take two L-shape rack mounting brackets and screws, install the brackets at the left and right sides of the equipment, as shown in the following figure.

The L-shape brackets are used to secure the gateway to the rack. The brackets cannot support the weight of the equipment alone. Prior to install the MX100G series chassis into rack, a supporting shelf must be installed in place where the gateway will sit.

Figure 3-1 Installation of MX100G Series L-shape Brackets



3.2.2 Mounting the Gateway


Attention should be paid during the installation:

- Ensure that the rack is firmly attached to the ground and stable.
- If the gateway is installed in a closed cabinet shelf, the cabinet must provide adequate air-flow so the equipments inside can be well ventilated.
- If multiple gateways are installed in a rack, it is recommended to keep at least 1/2U space between gateways for heat dissipation.

Follow the steps to install the gateway:

- Place the gateway on a shelf in the rack.
- Slide it to a proper position along the guide rails.
- Fix the rack-mount brackets to the rack posts with supplied Phillips screws. Make sure that the gateway is in level position and securely fixed as shown in following figure.

Figure 3-2 Mount MX100G to Rack



3.3 Installing Cables

3.3.1 Connecting Console Port


A CON should be provided by MX100G to check errors of the device. Connect the CON with computer's RS232 serial ports, then local computers can interwork with the device through simulating terminal program.

As to MX100G, RJ45 Plug is used. One port is applied for connecting CON, while the other is applied for DB9 Adapter to insert serial ports of configuration terminal. CON Ratio: 115200.

Console Port cable installation procedure is as followed:

Step1 Choose a terminal (PC).

Step2 Power off the terminal and connect RS232 port with the Console port.

Figure 3-3 Cable of Connecting MX100G CON

3.3.2 Connecting the Ethernet Cable

The MX100G has the dual-network-interface redundancy function. When one of the network interfaces is disconnected or does not work well, traffic services can be switched seamlessly to the other one.

The MX100G has two service interfaces, namely ETH1 and ETH2 for your choice. These two interfaces need to be connected to the same hub, LAN, or WAN. Only one of them works at a time. After Ethernet cables are inserted, check the indicator state of the interface that is connected first. If the indicator is steady green or blinking green, it indicates that the connection is established properly.

The MX100G has two auxiliary interfaces, namely AUX1 and AUX2. In most cases, no connection is required for auxiliary interfaces.

3.3.3 Connecting the T1/E1 Cable


MX100G offers RJ45 jack as T1/E1 connector for making ISDN connection with PBX or PSTN.

Please identify the connector type and interface impedance of the other side equipment before making T1/E1 connection.

If the other side equipment offers same RJ45 jack, use CAT5 cable with RJ45 plugs on both side to make T1/E1 cable connection. Be sure to match TX and RX pair according to the PIN specification when making the CAT5 cable.

If the other side equipment offers separate TX/RX coax connectors for T1/E1connection, use RJ45-Balun-Coax cable sets and follow the figure to make the connection.

Figure 3-4 Connecting the T1/E1 Cable



Note

The T1/E1 ports are numbered 1 to 4 from left to right. If the hardware configuration is 1 T1/E1, insert one end of the T1/E1 cable to the leftmost T1/E1 port on the MX100G.

3.3.4 Connecting the Grounding Cable

When install in equipment room facility providing independent grounding, it is required to connect the chassis ground tab on MX100G with the protective grounding system in this environment. Proper grounding not only provides a guarantee for safe operation of the equipment but also enhances the capacity of the equipment to resist disturbance and ensures the quality of voice communication.

The MX100G series main chassis and expansion chassis are equipped with a M4 grounding screw with a mark in their backs. Please use the M4 screw to connect the grounding wire.

3.3.5 Connecting the Power Cord

Before connect the power cord, make sure the AC power outlet is provided with a protective earth contact and the earth contact of the AC power source is proper grounded.



Note

Please contact the gateway supplier if the power LED does not light up after the power is turned on. Never install and uninstall the gateway or plug and unplug any cable on the gateway when the power is turned on.

Follow the steps to connect AC power cord:

Turn off the switch of AC power outlet.

MX100G use the shipped power cord to connect between the AC input at rear of the chassis and the AC power outlet.

Follow the steps to connect DC power cord:

Turn off the switch of DC power outlet.

Insert power cords to the socket shipped with the MX100G and fasten the cables. Then insert the socket to the device and fasten it.

3.3.6 Verifying Installation

Installation verification is extremely important, because operations of the gateway depend on its stability, grounding, and power supply.

Each time you turn on the power during the installation, verify that:

- Enough clearance has been reserved around the ventilation openings of the gateway and the workbench/rack is stable enough.
- The protection ground is connected properly.
- Proper power is used as specified.
- The gateway is correctly connected to console terminal and other devices.

4 Powering up the Gateway

4.1 Verification before Power-up

4.1.1 Checking Appearance

This is a review process of the installation work, including the chassis, wiring, connectors, ports, labels and site as described in the subsections.

Gateway

- Check whether there is adequate clearance around the gateway for thermal, and whether the workbench or rack for the mounting of the gateway is firm enough.
- Check whether the gateway is correctly connected to the configuration terminal and other devices.

Cable

- Check whether the Ethernet cable, the T1/E1 cables are connected properly.
- Check whether the grounding cable is connected properly.
- Check whether the power cord is connected to the proper power supply as required.

Port and Connector

- Check whether the ports and connectors are secured.

Equipment Room

- Check whether the temperature and humidity in the equipment room are within the proper range. The humidity should be kept at 10% to 90% non-condensing and the temperature should be kept at 0-4°C.

4.1.2 Checking Power Supply

Check whether the power supply is in normal operation with a multimeter.

4.2 Powering up the Gateway


Turn on the power switch. Check the status of PWR LED, and if it is lit the gateway is powered properly.

5 Parameter Setting

5.1 Login

Enter the gateway IP address in the browser address bar (For example, the default IP address 192.168.2.240), you can enter the login interface for gateway configuration by entering a password on the login interface.

Figure 5-1 Login Interface for MX100G Gateway Configuration



Both Chinese and English Languages are provided for the Web interface.

Logon users are classified into **administrator** and **operator**. The default passwords are **mx100** (lowercase letters required) and **operator**. The password is shown in a cipher for safety.

- The administrator can browse and modify all configuration parameters, and modify login passwords.
- The operator can browse and modify part of configuration parameters.

The gateways allow multiple users to log in:

- The administrator has permission for modification and the operator only has permission for browsing;
- When multiple users with same level of permission log in, the first has permission for modification, while the others only have permission for browsing.



Note

- The system will confirm timeout if users do not conduct any operation within 10 minutes after login. They are required to log in again for continuing operations.
- Remember to change administrator password at your first login.
- The device is only allowed to access using HTTPS. Since the factory default certificate is used a

prompt like "There is a problem with this website's security certificate" may occur. Click Continue to this website to access the login page.

5.2 Buttons Used on Gateway Management Interface

Save buttons are at the bottom of the configuration screens. It is used to submit configuration information. Users click Save button after completion of parameter configuration on a page. A success prompt will appear if configuration information is accepted by the system; if a "The configuration takes effect after the system is restarted" dialog box appears, it means that the parameters are valid only after a system restart; you are advised to click the Reboot button on the top right corner to enable the configuration after changing all parameters to be modified.

5.3 Basic Configuration

5.3.1 Network Configuration

Click **Basic** > **Network** tab to open the configuration interface.

Figure 5-2 Network Configuration Interface

The screenshot displays the Network Configuration Interface. At the top, there are navigation tabs: Basic, ISDN, Routing, Advanced, Security, Call Status, Logs, and Tools. Below these, a sub-menu shows Status, Network (selected), System, SIP, ISDN configuration, and FoIP. The main configuration area is divided into three sections: ETH, AUX, and STUN. The ETH section includes fields for Host name (MX100G), Setup (Static IP address), IP address (192.168.120.7), Subnet mask (255.255.255.0), Default gateway (192.168.120.1), Primary DNS server (. . .), and Secondary DNS server (. . .). The AUX section includes Mode (LAN port (IP address configura)), IP address (. . .), and Subnet mask (. . .). The STUN section includes a radio button for Enable (unselected) and a radio button for Disable (selected). A Save button is located at the bottom right of the interface.

Table 5-1 Network Configuration Interface

Name	Description
Host name	This is the equipment name of a configuration gateway. The default value is MX100G. Users can set a different name for each gateway to distinguish from each other according to the deployment plan. A host name can be a maximum of 48 characters, either letters (A-Z or a-z), numbers (0-9) and minus sign (-). It may not be null or space and it must start with a letter.
ETH	
Setup	Methods for obtaining an IP address. <ul style="list-style-type: none"> ● Static IP address: static IP address is used; ● Obtain an IP address automatically: use the dynamic host configuration protocol (DHCP) to obtain IP addresses and other network parameters; ● PPPoE: PPPoE service is used.
Username	Enter an authentication user name if PPPoE service is selected, and there is no default value.
Password	Enter an authentication password if PPPoE service is selected, and there is no default value.
IP address	If "Static IP" or "DHCP" is selected but an address fails to be obtained, the gateways will use the IP address filled in here. If the gateways obtain an IP address through DHCP, the system will display the current IP address automatically obtained from DHCP.
Subnet mask	The subnet mask is used with an IP address. When the gateway uses a static IP address, this parameter must be entered; when an IP address is automatically obtained through DHCP, the system will display the subnet mask automatically obtained by DHCP. It has no default value.
Default gateway	The IP address of LAN gateway. When the gateway obtains an IP address through DHCP, the system will display the LAN gateway address automatically obtained through DHCP. It has no default value.
DNS server	Obtained automatically: When the connection mode is "DHCP" or "PPPoE", the device uses the automatically obtained IP address of the DNS server. Specified manually: Use the DNS server addresses specified manually.
Primary DNS Server	If Specified manually is selected, the network IP address of the Primary DNS server must be entered, there is no default value.
Secondary DNS Server	If Specified manually is selected, the network IP address of the Secondary DNS server can be entered, there is no default value.
AUX	
Mode	<ul style="list-style-type: none"> ● Switching port: AUX and ETH ports are switch ports. The two ports share the IP address of ETH port. This mode is the factory default. ● LAN port (IP address configurable): In this mode, you can configure an IP address for AUX port.
IP address	The IP address used by an AUX interface to access the network gateway, which must be in different network segment with the IP address of the ETH interface.
Netmask	The subnet mask is used with an IP address. When the gateways use a static IP address of AUX, this parameter must be entered.

5.3.2 STUN (RFC3489)

Go to **Basic > Network**, and set to obtain the public IP address of the front-end router by using the STUN function.

Figure 5-3 STUN configuration interface

The screenshot shows the configuration interface for the STUN service. It features a top navigation bar with tabs: Basic, ISDN, Routing, Advanced, Security, Call Status, Logs, and Tools. Below this is a sub-navigation bar with tabs: Status, Network, System, SIP, ISDN configuration, and FoIP. The 'Network' tab is selected. The interface is divided into sections: 'AUX' with a 'Secondary DNS server' field; 'STUN' with 'Mode' (set to 'LAN port (IP address configura...)', 'IP address', and 'Subnet mask' fields; and 'STUN' settings including 'STUN' (radio buttons for 'Enable' and 'Disable'), 'Server IP address / Name', 'Server port', 'Session interval' (set to '0' with a range of '30 - 65535' seconds), and 'Operations' (radio buttons for 'SIP re-registration' and 'SIP re-registration & NAT address updating'). A 'Save' button is located at the bottom right.

Table 5-2 STUN parameters

Item	Description
STUN	The device periodically sends a STUN request to the STUN server to obtain the public IP address for the front-end router.
Server IP address / Name	Set the IP address or domain name of the STUN server. The default STUN server is the New Rock STUN server at stun.newrocktech.com .
Server port	Set the port of STUN server. It is 3478 by default.
Session interval	The interval at which the device sends a STUN request ranges from 30 to 3600 seconds.
operations	<ul style="list-style-type: none"> ● SIP re-registration: A re-registration of the SIP trunk is triggered upon the detection of the change of the public IP address of the device by using STUN query. Normally, the session interval of STUN request should be shorter than the registration period. <p>Note: The IP address obtained through STUN is used only for re-registration with the SIP server and it is not used in SIP message fields such as Via and Contact and SDP C field.</p> <ul style="list-style-type: none"> ● SIP re-registration & NAT address updating: A re-registration of the SIP trunk is triggered upon the detection of the change of the public IP address of the device by using STUN query. And the IP address obtained through STUN is used in SIP message fields such as Via and Contact and SDP C field.

5.3.3 VLAN

This page is available when the mode on Basic > Network is set to Switching port.
 After login, click **Basic>VLAN** to open the configuration interface.

Figure 5-4 VLAN Configuration Interface




Table 5-3 VLAN Configuration Parameters

Name	Description
Voice VLAN	Enable/disable voice VLAN.
SIP VLAN tag	Tag of the SIP VLAN. The value ranges from 3 to 4093.
SIP VLAN QoS	Priority of the SIP VLAN. The value ranges from 0 to 7. A larger value indicates a higher priority of a to-be-sent data packet.
RTP VLAN tag	Tag of the RTP VLAN. The value ranges from 3 to 4093.
RTP QoS	Priority of the RTP VLAN. The value ranges from 0 to 7. A larger value indicates a higher priority of a to-be-sent data packet.

5.3.4 System Configuration

Click **Basic > System** tab to open the system configuration interface.

Figure 5-5 System Configuration Interface

Basic	ISDN	Routing	Advanced	Security	Call Status	Logs	Tools
Status	Network	VLAN	System	SIP	ISDN configuration	FoIP	
Off-hook timer	<input type="text" value="12"/>	s (Range: 2 - 60, Default: 15)					
Interdigit timer	<input type="text" value="12"/>	s (Range: 2 - 60, Default: 5)					
Complete entry timer	<input type="text" value="3"/>	s (Range: 1 - 10, Default: 2)					
Codec	<input type="text" value="G.729A/20, G.711U/20, G.723/30"/> G.729A/20,G.711U/20,G.723/30,G.711A/20,iLBC/30,GSM/20						
DTMF transmission method	<input type="text" value="RFC 2833"/>						
RFC 2833 payload type	<input type="text" value="101"/>	Range: 96 to 127, Default: 101 ?					
DTMF tone duration ?	<input type="text" value="100"/>	ms (Range: 50 - 150, Default: 100)					
DTMF interdigit pause ?	<input type="text" value="100"/>	ms (Range: 50 - 150, Default: 100)					
Min. DTMF detection duration ?	<input type="text" value="48"/>	ms (The range must be 32 to 96 in multiples of 16)					
<input type="button" value="Save"/>							

Table 5-4 System Configuration Parameters

Name	Description
Off-hook timer	If a subscriber does not dial any digit within the specified time by this parameter after off-hook, the gateway will prompt to hang up with a busy tone. The value must be an integer, decimal points are not allowed. Unit: Seconds; Default value: 15 seconds.
Interdigit timer	The maximum time interval to dial the next digit. After timeout, the gateways will call out with the collected number. The value must be an integer, decimal points are not allowed. Unit: Seconds; Default value: 5 seconds.
Complete entry timer	The value must be an integer, decimal points are not allowed. Unit: Seconds; Default value: 2 seconds. This parameter is used with the "x.T" rule set in dialing rules. For example, there is "021.T" in the dialing rules table. When a subscriber has dialed 021 and has not dialed the next number within a set time by this parameter (e.g. 2 seconds), the gateways will consider that the subscriber has ended dial-up and call out the dialed number 021.
Codec	Codecs methods supported by the gateways include G729A/20, G723/30, PCMU/20, PCMA/20, iLBC/30 and GSM/20 (as shown in table 2-5). This parameter must be set due to no default value. Several encoding methods can configure in this item at the same time, separated with “,” in the middle; the gateways will negotiate with the platform in the order from front to back when configuring the codec methods
DTMF method	Transmission modes of DTMF signal supported by the gateways include Audio, RFC 2833 and SIP INFO. The default value is Audio. <ul style="list-style-type: none"> ● Audio: DTMF signal is transmitted to the platform with sessions; ● SIP INFO: Separate DTMF signal from sessions and transmit it to the platform in the form of SIP INFO messages; ● RFC 2833: Separate DTMF signal from sessions and transmit it to the platform through RTP data package in the format of RFC2833. ● RFC 2833 + SIP INFO: DTMF signal is transmitted simultaneously via RFC 2833 and SIP INFO.
2833 payload type	Used with RFC 2833 in the DTMF transmission modes. The default value of 2833 payload type is 101. The effective range available: 96-127. This parameter should match the setting of far-end device (e.g. platform).
DTMF on-time	This parameter sets the on time (in ms) of DTMF signal sent from FXO port. The default value is 100 ms. Generally, the duration time should be set in the range of 80-150 ms.

Name	Description
DTMF off-time	This parameter sets the off time (ms) of DTMF signal sent from FXO port. The default value is 100 ms. Generally, the interval time should be set in the range of 80-150 ms.
DTMF detection threshold	Minimum duration time of effective DTMF signal. Its effective range is 32-96 ms and the default value is 48 ms. The greater the value is set, the more stringent the detection is.

Table 5-5 Codec Methods Supported by Gateway

Codec Supported	Bit Rate (Kbit/s)	Time Intervals of RTP Package Sending (ms)
G729A	8	10/20/30/40
PCMU/PCMA	64	10/20/30/40
G723	5.3/6.3	30/60
iLBC	13.3/15.2	20/30
GSM	13	20

5.3.5 SIP Configuration

Click **Basic**> **SIP** tab to open the SIP configuration interface.

Figure 5-6 SIP Configuration Interface




Table 5-6 SIP Configuration Parameters

Name	Description
Signaling port	Configure the UDP port for transmitting and receiving SIP messages, with its default value 5060. If the MX100G is connected directly to the Internet, it’s recommended to change the default port value to prevent hacker attacks. Note: The signaling port number can be set in the range of 1-9999, but cannot conflict with the other port numbers used by the equipment.

Name	Description
Register server	Configure the address and port number of SIP register server, and the address and port number are separated by “:”. The register server address can be an IP address or a domain name. For example: 201.30.170.38:5060, register.com:5060. When a domain name is used, it is required to activate DNS service and configure DNS server parameters on the page of configuring network parameters.
Proxy server	Configure the IP address and port number of SIP proxy server, and the address and port number are separated by “:”. The proxy server address can be set to an IP address or a domain name. When a domain name is used, it is required to activate DNS service and configure DNS server parameters on the page of configuring network parameters. Examples of complete and effective configuration: 201.30.170.38:5060, softswitch.com:5060.
Backup proxy server	Configure the IP address and port number of backup proxy server.
Primary server heartbeat detect	Select the check box to enable and set the parameter OPTIONS request period, the device detects the failure condition of the proxy server (primary server) by periodically sending OPTIONS request to it. If the gateway does not receive the response to OPTIONS request, it will failover to the backup proxy server. After failover to the backup server, the gateway will still send OPTIONS to the primary server all the same. It switches back to the primary server once the response to the OPTIONS request is received.
OPTIONS request period	Set the period of sending OPTIONS request to the primary server.
Subdomain name	This domain name will be used in INVITE messages. If it is not set here, the gateways will use the IP address or domain name of the proxy server as the user-agent domain name. It has no default value. Do not set it to a LAN IP address.
Registrar mode	<ul style="list-style-type: none"> ● Per gateway: authenticate and register per gateway. ● Per SIP trunk: authenticate and register per SIP trunk provided by IMS platform. After this mode is selected and saved, a page of SIP Repeater is available under Basic sub-menu for configuring SIP trunk details.
User name	Configure the user name as part of the account for registration.
Authentication name	Configure the user name as part of the account for authentication.
Password	Password as part of account information is used for authentication by platform.
Registration period	Valid time of SIP re-registration in second. Its default value 3600.
TLS&SRTP	The device supports the ability to encrypt SIP protocol signaling by TLS, also support encrypted audio/media known as SRTP.
TLS server	Set to the address of a softswitch or IMS platform that supports TLS. After the configuration, the TLS function is automatically enabled.
Only Accepted Trusted Certificates	A new radio button of “Only Accept Trusted Certificates”. Support the new functionality of TLS certification validation. To upload the TLS certification, go access to the Advanced>Cert.
TLS Back Server	Support instant backup switchover whenever it is necessary.

5.3.6 SIP Trunk

Click **Basic > SIP Repeater** to open the interface.

Figure 5-7 SIP Trunk Settings Interface




Table 5-7 SIP Trunk Parameters

Item	Description
Routing	<ul style="list-style-type: none"> ● Sequential hunting: Make the outgoing call through the first available SIP trunk on the. ● Round-robin hunting: Make the outgoing call through the SIP trunk in Round-robin order.
ID	Line number
Register status	Indicate the status of registration: <ul style="list-style-type: none"> ● Register success: The SIP trunk can be used. ● Register failure: An error occurs during SIP trunk registration and the SIP trunk cannot be used. The issue can be determined according to the returned error code. ● Unregistered: The registration option is not selected. ● Timeout: The registration fails during the specified registration period and the SIP trunk cannot be used. You need to check whether the account of the SIP trunk is being used. ● DNS failure: The registration of the IP trunk fails due to a failure in domain name resolution. You should go to the Basic > Network page to check whether the DNS server is correctly configured.
Number	The number of the SIP trunk. It is provided by your ITSP. Note that all numbers cannot be repeated.
Concurrent calls	The number of concurrent calls supported by the trunk.
Username	Provided by your ITSP. It is used for authentication when registering an SIP trunk. If no username is entered, the number will be used for authentication.
Password	Provided by your ITSP. The password is encrypted by default. Please contact your service provider if you forgot the password. The registration password cannot contain “ ”.
Registration	Select this to enable registration.
Outbound call	<ul style="list-style-type: none"> ● Allowed: Allowed to make outbound calls; ● Pickup prohibit:Not allowed to make outbound calls.

5.3.7 ISDN Configuration

In case of full configurations, the MX100G has one 4T1/E1 card, with four interfaces numbering TDM1 to TDM4 from left to right. You are recommended to set parameters corresponding to the interface configured. Parameters for each interface are identical. You can set different parameter values for each interface as needed. For parameter setting, take the TDM1 as an example:

Click **Basic > ISDN configuration** tab to open the configuration interface.

Figure 5-8 ISDN Configuration Interface




Table 5-8 ISDN Configuration Parameters

Name	Description
DS1 type	DS1 Type configures if the T1/E1 interface operates as a T1 or E1 interface.
PCM codec	Allows configuring the PCM encoding type. Allowed settings are ULaw and ALaw.
Timing source	Set the clock synchronization source. It is TDM1 by default. <ul style="list-style-type: none"> ● If the TDM1/2/3/4 is chosen, it indicates that the MX100G synchronizes its clock with the opposite device connected to the first/second/third/forth TDM interface. ● If the Local is chosen, it indicates that the MX100G synchronizes with the local device.
Gain to IP	You can increase the value of this parameter to increase the voice volume received from ISDN network and sent to IP network.
Framing	If the MX100G DS1 Type is set to T1 then Line Framing can be set to D4, SF (Superframe), and ESF (Extended Superframe) mode. If the MX100G DS1 Type is set to E1 then Line Framing can be set to E1_MF_CRC mode.
Line code	If the MX100G DS1 Type is set to T1 then Line Code can be set to B8ZS or AMI. If the MX100G DS1 Type is set to E1 then Line Code can be set to HDB3.
Line impedance	The configuration is displayed when E1 is chosen, with the value of 120 OHM.
Line length	The configuration is displayed when T1 is chosen, with 0 dB and 7.5 dB for long haul and 36.67 m for short haul.

5.3.8 FoIP

Click **Basic >FoIP** tab to open the configuration interface.

Figure 5-9 FoIP Configuration Interface




Table 5-9 FoIP Configuration Parameters

Name	Description
Initial offer	
Codec	Click Edit , go to Basic>System page to configure. For details, see 5.3.4 System Configuration. When transport mode is set to G.711 passthrough, to ensure normal operation of the pass-through function, make sure that G.711U/20 or G.711A/20 is selected in Codec .
RTP port Min.	Click Edit , go to Advanced>Media stream page to configure. For details, see 5.3.4 System Configuration.
RTP port Max.	Click Edit , go to Advanced>Media stream page to configure. For details, see 5.3.4 System Configuration.
Fax configuration	
Transport mode	The device supports two fax modes: T.38 and G.711 pass-through. When fax messages are received or sent through an analog trunk, the G.711 pass-through mode is required. When fax messages are received or sent through an SIP trunk, a T.38 or a G.711 pass-through mode needs to be selected according to an actual requirement and the mode supported by the IP phone operation platform. If both T.38 and G.711 pass-through modes are supported, T.38 is recommended because it is more stable.
Adjustable parameters when G.711 pass-through is enabled (default values are recommended):	

Name	Description
Allow opposite terminal to switch to T.38	When the device sends a fax message in G.711 pass-through mode, if the other party sends a T.38 negotiation request, the device will respond to the request and automatically switch to the T.38 mode.
Receiving terminal	<ul style="list-style-type: none"> ● Re-INVITE: automatically select the codec according to the Re-INVITE negotiation result. ● Pass-through: To ensure normal operation of the pass-through function, make sure that G.711U/20 or G.711A/20 is selected in Codec.
Adjustable parameters when the T.38 is enabled (Default values are recommended.)	
Max. fax rate	9,600 is the maximum transmission rate of the fax service.
Port for fax transmission	<p>Set whether to use a new RTP port when the gateway switches to the T.38 mode. The default value is Use original RTP port.</p> <ul style="list-style-type: none"> ● Use a new port: Indicates that a new RTP port is used. ● Use original RTP port: Indicates that the original RTP port established during the call is used.
ECM mode	Enable the fax ECM mode. Disabled by default.
Output gain control	Set the increment and decrement of the T.38 fax transmission gain. The value ranges from -6 to +6 dB. The default value is 0 dB. -6 dB indicates an attenuation of 6 dB, and +6 dB indicates an amplification of 6 dB.
Packet size	Set a data frame packet interval for T.38. The options include 30 ms and 40 ms. The default value is 30 ms.
Signaling redundancy level	Set the number of redundant data frames in T.38 data packets. The value range is 0-6 frames, and the default value is 4 frames.

5.4 ISDN

In case of full configurations, the MX100G has one 4T1/E1 card, with four interfaces numbering ISDN1 to ISDN4 from left to right. You are recommended to set parameters corresponding to the interface configured. Parameters for each interface are identical. You can set different parameter values for each interface as needed. For parameter setting, take the ISDN1 as an example.

Click **ISDN > ISDN1** tab to open the configuration interface.

Figure 5-10 ISDN Configuration Interface

The screenshot displays the MX100G Admin interface for ISDN configuration. The top navigation bar includes 'Basic', 'ISDN', 'Routing', 'Advanced', 'Security', 'Call Status', 'Logs', and 'Tools'. The 'ISDN' section is active, showing configuration for ISDN 1. The interface is organized into several sections:

- Basic Configuration:** Fields for Name (TEST1), User name, Authentication name, and Registrar password. An 'Enable' checkbox is checked.
- Application:** Radio buttons for Collecting CDPN (Overlap, Enbloc), D channel (Timeslot 16, Timeslot 24), and Switch type (User, Network). A dropdown for Signaling Standard is set to CCITT. A 'Save' button is at the bottom.
- D channel service message:** A checkbox that is unchecked.
- Nail-up connection:** A checkbox that is unchecked.
- CPN category:** Radio buttons for Standard and Nonstandard.
- CPN presentation:** A checkbox that is unchecked.
- CDPN category:** Radio buttons for Standard and Nonstandard.
- Busy line handling:** Radio buttons for Announcement and Hang up.
- CID exclusive:** A checkbox that is unchecked.
- Second stage dialing:** Radio buttons for Enable, Prompt (Announcement, Dial tone), and Calling party number (Originating number, Original CDPN).
- Called party number (CDPN):** Radio buttons for Original CDPN + Second dialed number and Second dialed number.
- Digit transformation:** A text field for TDM.
- ISDN Layer 1:** Status (Link down), BERT (Duration, seconds), and Near End Loop Back (Start).
- ISDN-D channel:** Status (Out of Service).
- ISDN-B channel:** Status (Out of Service).

A legend at the bottom indicates: Red: channel disabled. Yellow: forbid calls from IP to ISDN. Green: channel is clear. A 'Save' button is located at the bottom of the page.

Table 5-10 ISDN Configuration Parameters

Name	Description
Name	Display the name of an ISDN interface.
User name	Fill in the registration account.
Authentication name	Fill in the Authentication account.

Name	Description
Registrar password	The password is the verification password consisting with digits, uppercase letters or lowercase letters at least one item must be selected.
Enable	Enable an ISDN interface.
Application	
Collecting CDPN	Choose a collecting mode: Overlap or En-bloc.
D channel	A signalling channel. The default value is timeslot 16 for E1 services and timeslot 24 for T1 services.
Switch type	Set the interface protocol on the user side or network side. If the opposite terminal uses network side, the local terminal should choose user side.
Signaling Standard	The variation of ISDN PRI signalling standards: CCITT, NI-2, DMS100, DMS250 and 5ESS. You are recommended to select NI-2 for T1 card and CCITT for E1 card.
Circuit hunting	Search mode of idle timeslot: Forward, Backward and Cycle. Users can choose from the drop-down box. <ul style="list-style-type: none"> ● Forward: In the case of an incoming call, the MX100G first checks whether timeslot 1 is idle. If not, the MX100G checks whether timeslot 2 is idle. The process proceeds in the ascending order until an idle timeslot is found. ● Backward: The MX100G searches for an idle timeslot in the descending order. ● Cycle: The MX100G searches for the next idle timeslot from left to right.
D channel service message	Setting for enabling the D channel service message.
Nail-up connection	Setting for enabling P2P connection (the called party number and channel ID are not required).
CPN category	Setting the Standard CPN calling party number category subfield. For the details, please refer to the ITU-T Q.931 protocol.
CPN presentation	Setting CPN calling party number presentation subfield. For the details, please refer to the ITU-T Q.931 protocol.
CDPN category	Setting the Standard CDPN called party number category subfield.
Busy line handing	The call processing mode for busy line is Announcement or Hang up.
CID exclusive	For the opposite terminal to change the line, choose Exclusive in CID.
Second stage dialing	
Enable	Enable the second dial tone and detect the DTMF number.
Prompt	Set the mode of second dial tone: Announcement or Dial tone.
Calling party number(CPN)	Set the display mode of calling party number: Originating number or Original CDPN.
Called party number (CDPN)	Set the display mode of called party number: Original CDPN + Second dialled number or Second dialled number.

Name	Description
Digit transformation	Number Transformation on each T1/E1 link. Rule format for number transformation on a single T1/E1 link: Operated number: Operation rule set/Operated number: Operation rule set For details about operated numbers and translation rules, see Table 5-11 Operated Numbers and Translation Rules.
ISDN Layer 1	
Status	Indicates whether the E1/T1 port is connected. “Link up” indicates connected, “Link down” indicates disconnected.
BERT	Set the duration, in the unit of seconds, minutes, hours, or days. After that, you can click Start to view the progress bar and the Stop button, as shown in the following figure. You can click Stop to cancel the testing process.
Near End Loop Back	Enable the loop back function for the remote device by clicking Start .
ISDN-D channel	Display the state of the ISDN-D channel: In service or Out of service.
ISDN-B channel	Displays the indicator state of a specific ISDN-B channel. <ul style="list-style-type: none"> ● If you click the channel in green, the indicator turns yellow and the call from IP to ISDN on the T1/E1 line is prohibited. The call from ISDN is not affected. ● If you click Block and choose a specific channel, the indicator of the chosen channel turns red. ● If you click Unblock and choose a blocked channel, the indicator of the chosen indicator turns green. ● If you click Query and choose a channel, the channel state is refreshed. ● If you click Restart and choose a channel, the choose channel restarts.

Table 5-11 Operated Numbers and Translation Rules

Operated Number	The four following types of operated numbers exist: <ul style="list-style-type: none"> ● InCPN: Operates the calling numbers of calls from ISDN. ● InCDPN: Operates the called numbers of calls from ISDN. ● OutCPN: Operates the calling numbers of calls to ISDN. ● OutCDPN: Operates the called numbers of calls to ISDN.
Operation Rue Set	There are four types of operation rules: matching rules, substitution rules, insertion rules, and deletion rules. The operation rule set is a combination of the four types of rules. If the user does not set a matching rule in the operation rule set, the operation applies to all numbers corresponding to the operated number. Different types of rules are separated by a slash. Rules are executed in sequence from left to right.
Matching Rule	Matching rule CnSmmm or C-nSmmm, where n is an integer greater than or equal to 1, and mmm is a number string. <ul style="list-style-type: none"> ● CnSmmm: Matches the number string mmm behind S from left to right, starting from the nth digit of the number on the left. ● C-nSmmm: Matches the number string mmm behind S from right to left, starting from the nth digit of the number on the right.

Replacing Rule	<p>Replacing rule RnSmmm or R-nSmmm, where n is an integer greater than or equal to 1, mmm is a number string, and Y is assumed to be the length of mmm.</p> <ul style="list-style-type: none"> ● RnSmmm: Replaces the number string of the Yth digit starting from the left nth digit of the number with the number string mmm behind S from left to right. ● R-nSmmm: Replaces the number string of the Yth digit starting from the right nth digit with the number string mmm behind S from right to left.
Inserting Rule	<p>Inserting rule InSmmm or I-nSmmm, where n is an integer greater than or equal to 1, and mmm is a number string.</p> <ul style="list-style-type: none"> ● InSmmm: Inserts the number string mmm behind S from left to right into the number of the Yth digit starting from the left nth digit. ● I-nSmmm: Inserts the number string mmm behind S from right to left into the number of the Yth digit starting from the right nth digit.
Deleting Rule	<p>Deleting rule DnSy or D-nSy, where n is an integer greater than or equal to 1, and y is the number of digits of the number string.</p> <ul style="list-style-type: none"> ● DnSy: Deletes the number of the Yth digit, starting from the nth digit on the left. ● D-nSy: Deletes the number of the Yth digit, starting from the nth digit on the right.

Requirements

- Substitute the prefix 66 in the called numbers of calls to ISDN1 with the prefix 71.
- For calls from ISDN1, delete the first two digits of the calling numbers that start with the prefix 88.

The TDM1 rule is as follows:

OutCDPN:C1S66/R1S71/InCPN:C1S88/D1S2

Description

- In this rule, OutCDPN:C1S66/R1S71 is used to operate the called numbers of calls to ISDN1. If the called number of a call is 6602, it conforms to the matching rule C1S66. Then, the substitution rule R1S71 is applicable; that is, the called number 6602 is substituted by 7102.
- In this rule, InCPN:C1S88/D1S2 is used to operate the calling numbers of calls from ISDN1. If the calling number of a call is 88123, it conforms to the matching rule C1S88. Then, the deletion rule D1S2 is applicable; that is, the first two digits of 88123 are deleted so that the calling number 88123 is translated to 123.

5.5 Routing

5.5.1 Digit Map




Note

In most situations, dialing rules need to be configured only for second dial on the MX100G.

Click **Advanced > DigitMap** tab to open the digit map interface.

Figure 5-11 Configuration Interface for Digit Map



Digit map rules are used to effectively judge if the received number sequence is completed, for the purpose of ending up receiving numbers and sending out the received numbers. The proper use of digit map rules can help to reduce the connection time of telephone calls.

The maximum number of rules that can be stored in gateways is 520. The total length of dialing rules table (the total length of all dialing rules) cannot be more than 3000 bytes.

The default digit map only contains system function rules. To customize the digit map, please choose the country in **Advanced >Tones** and input the rules you want in the text box.

The following provides a description of typical rules:

Table 5-12 Description of Digit map

Digit map	Description
x	Represents any number between 0-9. The x sign can match with any numbers. For example, the x sign can match with 1 or 2.
.	Represents more than one digit between 0-9. The sign can match with number with any length. For example, the value 1 can match with 11 or 123.
xxxxxxxx.T	For a number with 10 digits, or less than 10 digits, the device terminates receiving digits and sends detected numbers if the duration of no dialing period exceeded the value of the Interdigit timer parameter. For a number with more than 10 digits, the device terminates receiving digits and sends detected numbers if the duration of no dialing period exceeded the value of the Complete entry timer parameter. Interdigit timer and Complete entry timer can be set on Basic>System page.
x.#	Any length of telephone number starting with any number between 0-9. If subscribers press # key after dial-up, the gateways will immediately end up receiving numbers and send all the numbers before # key.
[2-8]xxxxxx	The gateway terminates receiving digits after receiving 7 digits starting with a digit between 2 to 8.
02xxxxxxxx	The gateway terminates receiving digits after receiving 11 digits starting with 02.
013xxxxxxxx	The gateway terminates receiving digits after receiving 12 digits starting with 013.
13xxxxxxxx	The gateway terminates receiving digits after receiving 11 digits starting with 13.

Digit map	Description
11x	The gateway terminates receiving digits after receiving three digits starting with 11.
9xxxx	The gateway terminates receiving digits after receiving five digits starting with 9.
17911 (e.g.)	Send away when the set number, e.g. 17911, is received.

Dial rules by default as follows:

01[3, 5, 8] xxxxxxxxx

010xxxxxxxx

02xxxxxxxx

0[3-9] xxxxxxxxx

120

11[0, 2-9]

111xx

123xx

95xxx

100xx

1[3-5, 8] xxxxxxxxx

[2-3, 5-7] xxxxxxx

8[1-9] xxxxxx

80[1-9] xxxxx

800xxxxxxxx

4[1-9] xxxxxx

40[1-9] xxxxx

400xxxxxxxx

xxxxxxxxxx.T

x.#

#xx


*xx

##


5.5.2 Routing Table

Click **Routing > Routing Table** tab to open the configuration interface.

Figure 5-12 Configuration Interface for Routing Table



Click **Help** to open the illustrative interface for routing configuration.



The routing table with 500 rules in capacity provides two functions including digit transformation and call routing assignment. Here are the general rules applied by gateways when executing the routing table.



Note

- Rules must be filled out without any blank at the beginning of each line; otherwise the data can't be validated even if the system prompts successful submittal.
- The routing table is empty by default. The gateways will point a call to the SIP proxy server when there is no matched rule for the call.

The format of number transformation is

Source Number Handle [Parameter]

Or

Source Number ROUTE Destination [Parameter]

The format of number transformation is

Source Number Replacement Method

For example: **FXS 021 REMOVE 3** means remove the prefix 021 of the called number for calls from the IP.

The format of routing rules is:

Source Number ROUTE Destination

For example:

IP 8621 ROUTE ISDN 1

Indicates that the call with the called party number starting with 8621 is sent from the IP network to the first E1 interface.

Detailed definitions of source and number, number transformation methods and routing destination are shown below.

Table 5-13 Routing Table Format

Name	Description
Source	Source can be ISDN or IP. When source is IP, an address can optionally be specified, e.g., [xxx.xxx.xxx.xxx] or [xxx.xxx.xxx.xxx:port]. There are two source types: IP and ISDN. The IP source can be any of the following: <ul style="list-style-type: none"> ● Any IP address, represented by IP. ● A specified IP address, represented by IP[xxx.xxx.xxx.xxx]. ● A specified IP address and port number, represented by IP[xxx.xxx.xxx.xxx:port] (port specifies a source port number, such as 5060).
Number	It could be a calling party number with the form of CPN + number, such as CPN6034340633 or a called party number with the form of number. The number may be denoted with digit 0-9, “*”, “:”, “#”, “x”, etc., and uses the same regular expression as that of dialing rules. Here are examples of the form of number: <ul style="list-style-type: none"> ● Designate a specific number: eg.114, 61202700 ● Designate a number matching a prefix: such as 61xxxxxx. Note: the matching effect of 61xxxxxx is different from that of 61x or 61. Number matching follows the principle of minimum priority matching ● Specify a number scope. For example, 268[0-1, 3-9] specifies any 4-digit number starting with 268 and followed by a digit between 0-1 or 3-9 Note: Number matching follows the principle of minimum matching. For example: x matches any number with at least one digit; xx matches any number with at least two-digit; 12x matches any number with at least 3-digit starting with 12.

Table 5-14 Number Transformations

Processing Mode	Description and Example
KEEP	Keep number. The positive number behind KEEP means to keep several digits in front of the number; the negative number means to keep several digits at the end of the number. Example: IP 02161202700 KEEP -8 Keep the last 8 digits of the called number 02161202700 for calls from IP. The transformed called number is 61202700.

Processing Mode	Description and Example
REMOVE	<p>Remove number. The positive number behind REMOVE means to remove several digits in the front of the number; the negative number means to remove several digits at the end of the number.</p> <p>For example: IP 021 REMOVE 3 Any number start with 021, the 021 prefix is removed.</p>
ADD	<p>Add prefix or suffix to number. The positive number behind ADD is the prefix; the negative number is suffix.</p> <p>Example 1: IP CPN6120 ADD 021 CPN number start with 6120, prefix 021 is added.</p> <p>Example 2: IP CPN6120 ADD -8888 CPN number start with 6120, 8888 is appended.</p>
REPLACE	<p>Number replacement. The replaced number is behind REPLACE.</p> <p>Example: ISDN CPN88 REPLACE 2682000 CPN number started with 88, the prefix "88" is replaced with 2682000.</p> <p>Other use of REPLACE is to replace the specific number based on other number associated with the call. For example, replacing the calling party number according to the called party number.</p> <p>Examples: ISDN 12345 REPLACE CPN-1 Indicates that the tail digit is deleted from the caller number in correspondence with the called party number 12345 from ISDN.</p>
END or ROUTE	<p>End of number transformation. From top to bottom, number transformation will be stopped when END or ROUTE is encountered; the gateways will route the call to the default routing after meeting END, or route the call to the designed routing after meeting ROUTE.</p> <p>Example 1: IP 12345 ADD -8001 IP 12345 REMOVE 4 IP 12345 END Indicates that the called party number from an IP network starting with 12345. The first order indicates it is suffixed with 8001, the second order indicates it removes 4 digits and the third order indicates it ends the previous operations.</p> <p>Example 2: IP[222.34.55.1] CPNX REPLACE 2680000 IP[222.34.55.1] CPNX HIDE IP[222.34.55.1] CPNX ROUTE ISDN 2 Indicates that any calling party number from the IP address 222.34.55.1 is replaced by 2680000. The calling party number is hidden and the call is sent to the second E1. Note: The hiding of the calling party number can be enabled only when the operator can provide the corresponding support as well.</p>
CODEC	<p>Designate the use of codec, such as PCMU/20/16, where PCMU denotes G.711, /20 denotes RTP package interval of 20 milliseconds, and /16 denotes echo cancellation with 16 milliseconds window. PCMU/20/0 should be used if echo cancellation is not required to activate.</p> <p>Example: IP 6120 CODEC PCMU/20/16 PCMU/20/16 codec will be applied to calls from IP with called party number starting with 6120.</p>


Processing Mode	Description and Example
RELAY	<p>Insert prefix of called party number when calling out. The inserted prefix number follows behind REPLAY.</p> <p>Example: IP 010 RELAY 17909</p> <p>For calls from IP with called party number starting with 010, digit stream 17909 will be outpulsed before the original called party number is being sending out.</p>
SEND180	<p>Force send 180 on ring back</p> <p>Example: IP CPN2 SEND180</p> <p>CPN number start with 2, always send 180 on ring back.</p>
SEND183	<p>Force send 183 on ring back.</p> <p>Example: IP CPN3 SEND183</p> <p>CPN number start with 3, always send 183 on ring back (voice cut through).</p>
HIDE	<p>Calling party number presentation.</p> <p>Example: IP[61.2.44.53:5060] CPNX HIDE</p> <p>Any call from 61.2.44.53:5060, calling party number presentation restriction is applied.</p> <p>Note: The hiding of the calling party number can be enabled only when the operator can provide the corresponding support as well.</p>

Table 5-15 Routing Destination

Destination	Description and Example
ROUTE NONE	<p>Calling barring.</p> <p>Example: IP CPN[1,3-5] ROUTE NONE</p> <p>Bar all calls from IP, of which the calling numbers start with 1, 3, 4, 5.</p>
ROUTE ISDN	<p>Route a call to ISDN.</p> <p>IP 8621 ROUTE ISDN 1 IP CPN8620 ROUTE ISDN 2</p> <p>call has 8621 prefix, route to ISDN span 1 calling party number started with 8620, route to ISDN span 2</p>
ROUTE IP	<p>Route a call to the IP platform.</p> <p>Example: FXS 021 ROUTE IP 228.167.22.34:5060 228.167.22.34:5060 is the IP address of the platform.</p> <p>ISDN 021 ROUTE IP 228.167.22.34:5060 ISDN 020 ROUTE IP 61.234.67.89:5060</p> <p>Indicates that the call from the PSTN, with the called party number starting with 021 will be sent to the platform with the IP address of 228.167.22.34; the call with the called party number starting with 020 will be sent to the platform with the IP address of 61.234.67.89.</p>

5.5.3 Application Examples of Routing Table

Application requirements



- Selecting an E1 line based on calls from the IP network.
- Replacing the calling party number section of an IP call with a shared number.
- Permitting the IP call with the number only in the calling party number section, not other ID sections.
- Hiding the calling party number of an IP call by replacing the entire calling party number section with one digit number.
- Specifying a voice coding for a certain kind of clients.

Routing setting

```
IP CPNX REPLACE 18710095 (B)
IP CPN2 CODEC PCMU/20/64 (E)
IP CPNX HIDE (D)
IP[221.38.112.26] CPN2 ROUTE ISDN 3 (A)
IP CPN[1,4-5] ROUTE NONE (C)
```

- Calls from 2680023 to 61231001 are matched with configurations of (B), (E), (D), and (A). The calling party number 2680023 is replaced with 18710095, with the codec of pcmu/20/64. The calling party number is hidden and the call is sent to the third E1 line.
- Calls from 3682576 calls 61231002 are matched with configurations of (B) and (D). The calling party number 3682576 is replaced with 18710095 and is then hidden. Configurations (A), (E), and (C) are not matched.
- Calls from 4680058 and 5680069 to 61231001 are matched with the configuration (C), and calls are prohibited.

5.6 Advanced Configurations

5.6.1 System

Click the label of **Advanced > System** to open this interface.

Figure 5-13 System Advanced Configuraiton Interface

The screenshot shows the 'Advanced' configuration page of the MX100G SIP-ISDN Gateway. The top navigation bar includes 'Basic', 'ISDN', 'Routing', 'Advanced' (selected), 'Security', 'Call Status', 'Logs', and 'Tools'. Below this, there are sub-tabs: 'System', 'Media stream', 'SIP', 'RADIUS', 'Tones', and 'System time'. The main content area is divided into several sections:

- NAT:**
 - NAT traversal: Dynamic NAT (dropdown menu)
 - Refresh period: 15 (input field) s (more than 14, Default 15)
 - SDP address: External Network IP Address, Internal Network IP Address
- Auto provision:**
 - Enable, Disable
- TR069:**
 - ACS-URL: [input field] The URL of the ACS to which the device will try to connect and send messages, such as http://192.168.2.7:8088.
 - Username: [input field]
 - Password: [input field]
 - Serial number: [input field]
 - Periodic inform enable: On, Off
 - Periodic inform interval: 0 (input field) s (Range: 60 - 7200)
 - Connection request URL: [input field]
 - Connection request username: [input field]
 - Connection request password: [input field]
- RTP traverse:**
 - Enable:

A 'Save' button is located at the bottom right of the configuration area.

Table 5-16 Advanced System Configuration Parameters

Name	Description
NAT	
NAT traversal	Gateways support several mechanisms for NAT traversal. Usually, static NAT is used when fixed public IP address is available. It's necessary to perform port mapping or DMZ function on router when choosing dynamic or static NAT.
Refresh period	The refresh time must be filled in here when choosing dynamic NAT or STUN traversal. Besides, refresh time interval shall be determined by giving consideration into the NAT refresh time of the LAN router which the gateway is located. Gateway's NAT holding function will carry out periodically operation according to this parameter. With second as its unit, default value of 60 seconds.
SDP Address	This parameter determines the IP address used in transmitted SDP. <ul style="list-style-type: none"> ● NAT IP Address: Apply NAT address into the transmitted SDP; ● Local IP Address: Apply the gateway's IP address into the transmitted SDP. Note: The parameter should come into effect only on condition that gateway successfully obtained NAT address.
NAT IP address	This parameter must be filled when using static NAT traversal, in which IAD works under LAN and the WAN address is fixed. The WAN address should be filled in this field, which will be used in SDP. This parameter can be set in IP address format or hostname format (note: DNS service should be activated when hostname format is used). There is no default value for this field.

Name	Description
Auto Provision	Note: For detailed configurations, refer to the <i>MX Gateway Auto Provisioning Configuration Manual</i> .
Enable	Tick it to use the auto provision function.
Obtain ACS address via DHCP option 66	ACS (Auto Provisioning Server) address is obtained by using DHCPoption66.
ACS URL	Manually configure the ACS address, which can be the TFTP, FTP, HTTP or HTTPS server. <ul style="list-style-type: none"> ● <i>tftp://ACS address</i> ● <i>ftp:// ACS address</i> ● <i>http:// ACS address</i> ● <i>https://ACS address</i>
User name	Input a user name for accessing the ACS. Note: If the ACS is a TFTP server, the username and the password are not displayed.
Password	Input a password for accessing the ACS.
Firmware upgrade	Enable firmware download and update using ACS. Note: The firmware can be a tar.gz file or an img file.
Upgrade mode	The following modes are available. <ul style="list-style-type: none"> ● Power on: the gateway detects whether there are configurations and firmware to be updated when the device is powered on. ● Power on + Periodical: when the device is powered on, the gateway first checks whether there are configurations and firmware to be updated, and then periodically performs checking based on the set times.
Upgrade period	When Power on+Periodical is set, this parameter specifies the interval for periodic automatic upgrades. The default range is 3600 seconds. The value range is 5 to 84600 second.

TR069

ACS-URL	Specify the URL of the ACS.
Username	Set the user name used by the device to authenticate with the ACS.
Password	Set the password used by the device to authenticate with the file server
Serial number	Information of the device vendor, which may be used to indicate the primary service provider and other provisioning information to the ACS. It can be numbers or English letters.
Periodic inform enable	A switch used to specify whether to periodically report to the ACS.
Periodic inform interval	The interval for reporting to the ACS.
Connection request URL	The address used for the ACS to connect back to the device.
Connection request username	The account used for the ACS to connect back to the device, for example, admin.
Connection request password	The password used for the network management server to connect back to the device.
RTP Traverse	
Enable	Select to enable the RTP traverse function.

5.6.2 Media Stream

Click the label of **Advanced > Media Stream** to open this interface.

Figure 5-14 Media Stream Configuration Interface

Table 5-17 Media Stream Configuration Parameters

Name	Description
RTP port Min.	The minimum value of UDP ports for RTP transmission and receiving, and the parameter must be greater than or equal to 3000. The value is recommended to be equal or greater than 10000. Note: each phone call will occupy RTP and RTCP ports.
RTP port Max.	The maximum values of UDP ports for RTP’s transmission and receiving. It’s advisable to be greater than or equal to “2× number of lines + min. RTP port”.
iLBC payload type	Set the RTP payload type of iLBC, and the default value is 97. Accepted value is 97-127. The parameter shall be configured in conformity to that of platform.
G.723.1 rate	Set G.723.1 coding rate, the default value is 6300. The optional parameters are followings: ● 5300: the Bit rate is 5.3k per second; ● 6300: the Bit rate is 6.3k per second
RTP_TOS	This parameter specifies the quality assurance of services with different priorities. The factory setting is 0x0C. For example, TOS=0xB8 indicates that the priority of the service quality is 5, with a requirement on low delay and high throughput. There is no requirement on the reliability.
Min. Jitter buffer	RTP Jitter Buffer is constructed to reduce the influence brought by network jitter. This default value is 3.
Max. Jitter buffer	RTP Jitter Buffer helps to reduce the influence brought by network jitter. The default value is 50.
RTP drop SID	Determine whether to discard received RTP SID voice packets. By default, SID voice packets will not be dropped. Note: RTP SID packets should be dropped only when they are in unconformity to the specifications. Nonstandard RTP SID data could generate noise for calls.
Enable VAD	Only applicable to G.723, GSM, iLBC. In case of selecting this parameter, it will not send any voice packet during mute period. By default, this is selected.
RTP destination address	This parameter determines where to obtain the IP address of the receiving side for RTP packets. By default, the IP address is obtained “From SDP global connection”. ● From SDP global connection: Obtain the IP address from SDP global connection; ● From SDP media connection: Obtain the IP address from SDP Media Description.

5.6.3 SIP Configuration

Click the label of **Advanced > SIP** to open this interface.

Figure 5-15 SIP Related Configuration Interface




Table 5-18 SIP Related Configuration Parameter

Name	Description
SIP configuration	
PRACK	Determine whether to activate Reliable Provisional Responses. (RFC 3262)
Early media	Enable RFC5009. It is not enabled by default.
Media direction attribute	<p>Set parameter values of the P-Early-Media header field:</p> <ul style="list-style-type: none"> ● Supported ● Sendrecv ● Sendonly ● Recvonly ● Inactive <p>The fields vary according to the type of SIP message. They should be set as required by the peer end. Note: This parameter can be configured after Early media is selected.</p>
Session timer	Choose to activate session refresh (Session Timer, RFC 4028). By default, session timer is not activated.
Session interval	Set the session refresh interval, the gateway will enclose the value of Session-Expires into INVITE or UPDATE messages. Default value is 1800 in second.

Name	Description
Minimum timer	Set the minimum value of session refresh interval.
Request/Response message Configuration	
Port for sending response	Select the port for sending SIP signaling responses: <ul style="list-style-type: none"> ● Using received port to send response ● Using 5060
Contact field in REGISTER	Choose the registration mode of gateway under LAN traversal circumstance, the default is NAT IP Address . <ul style="list-style-type: none"> ● LAN IP address: Keep original content of Contact when register; ● NAT IP address: Use the NAT information returned by registration server.
Domain name in REGISTER	The default is Domain name . <ul style="list-style-type: none"> ● Domain name: Complete domain name used for registration (for example: 8801@registrar.newrock.com); ● Subdomain name: Only use the common part of the name of domain (for example: 8801@newrock.com).
Subdomain name	While registering account, only fill in the public segment (eg. 8801@newrock.com) instead of reserving the domain name
Via field	Choose whether to use NAT IP address or LAN IP address for “Via” header field value, the default is NAT IP address .
To header field	Choose whether to apply Domain name or Outbound proxy to “To” header field, the default is Domain name .
Call-ID header field	Choose whether to fill Call ID field with host name or local IP, the default is local IP address .
Obtain called party number from	Choose whether the gateway acquires the called number from Request Line header field or To header field. The default is from Request Line .
Calling party number in call transfer	Under call forwarding, the calling party number sent can be choose from Originating number or Forwarding number being set for sending, the default is Forwarding number . For example: the subscriber line 2551111 on the gateway activates call forwarding feature and set the destination to 3224422. When caller with 13055553333 calls 2551111, the call will be forwarded to 3224422: <ul style="list-style-type: none"> ● If choose Originating number, the number 13055553333 will be sent to 3224422 as calling party number. ● If choose Forwarding number, the number 2551111 will be sent to 3224422 as calling party number.
Replace 18X with 180	<ul style="list-style-type: none"> ● Send 180: If this parameter is set to enable, the gateway will map all alerting messages (ALERTING with and without in-band indicator) to 180. An example of when this parameter would be enabled is when an IAD does not support a 183 message. ● Send 18x: If this parameter is set to enable, the 18x message will be sent.
Do not validate Via	Set whether to ignore Via field, By default, Via is ignored.
Re-register on INVITE failure	Set whether to activate registration when SIP message of INVITE is failed or time expired, and by default, re-registration is not selected.
IMS	
IMS	Enable interworking with IMS.
Obtain caller ID info from	For a received call of a SIP trunk, you can set to get the Caller ID from P-Asserted-Identity header or From header in the SIP message.
Access network info	The IP address and port number of the access network. For example: 192.168.100.200:5060. It is optional, input only when the IMS service provider requires.

5.6.4 RADIUS

Click the label of **Advanced > RADIUS** to open this interface.

Figure 5-16 RADIUS Configuration Interface

Table 5-19 RADIUS Configuration Parameter

Name	Description
Primary server	Set IP address and port number of preferred Radius server. Note: if the port number is not configured yet, please use Radius default port number of 1813.
Key	Set the share key to be used for encrypted communications between Radius client and server. Note: the share key should be configured the same for both client and server side
Secondary server	Set the IP address and port number of standby Radius server. When the fault appears in communications between gateway and preferred Radius server, the gateway will automatically activate standby Radius server. Note: in case of no configuration of port number, use default port number of 1813.
Key	The share key for communications between Radius client and standby Radius server. Note: the key should be configured the same for both client and server side
Retransmit timer	Set the amount of overtime on response after transmission of Radius message, the default is 3 seconds. The retransmission will be performed If no response is given after the timeout.
Retransmit times	Set the times of retransmission of Radius message when no response is received default is 3 times.
Trigger	<ul style="list-style-type: none"> ● IP side: when this is selected the call information on the SIP side will be sent to the Radius server. ● IP and TDM side: when this is selected the call information on the SIP side as well as on the ISDN side will be sent to the Radius server.
CDR type	<ul style="list-style-type: none"> ● Outbound: Set whether to send RADIUS charge message for outbound calls; ● Inbound: Set whether to send RADIUS charge message for inbound calls; ● Answered: Set whether to send RADIUS charge message when calls are connected; ● Unanswered: Set whether to send RADIUS charge message for unanswered calls.

5.6.5 Tones

Click the label of **Advanced > Tones** to open this interface.

Figure 5-17 Tones Configuration Interface




Table 5-20 Tones Configuration Parameters

Name	Description
Country/region	There are progress tone plans for several countries and regions which are pre-programmed in gateways. Users may also specify the tone plan according to the national standard. Gateways provide tone plan for the following countries and regions: China; the United States; Singapore, Israel, Malaysia, Indonesia, United Arab Emirates, Zimbabwe, France; Italy; Germany; Mexico; Chile; Russia; Japan; South Korea; Hong Kong; Taiwan; India; Sudan; Iran; Algeria; Pakistan; Philippines; Kazakhstan;
Dial tone	Prompt tone of off-hook dialup
Second dial tone	Second stage dial tone.
Stutter dial tone	Prompt of voice mail, or when the subscriber line is set with “Do not Disturb Service and Call Transfer”.
Busy tone	Busy line prompt.
Congestion tone	Notification of call set up failure due to resource limit.
Ring back tone	The tone sent to caller when ringing is on.
Off-hook warning tone	Reminds the subscriber when the phone is off-hook and no dialup has occurred.
Call waiting tone	Prompt the subscriber that another caller is attempting to call.
Confirmation tone	Confirms feature codes are being entered.

Here are examples that illustrate the various call-progress tones

- 350+440 (dial tone)
Indicates the dual–frequency tone consisting of 350 and 440 Hz
- 480+620/500,0/500 (busy)
Indicates the dual–frequency tone consisting of 480 and 620 Hz, repeated playing with 500 milliseconds on and 500 milliseconds off.
Note: 0/500 indicates 500 milliseconds mute.
- 440/300,0/10000,440/300,0/10000

Indicates 440 Hz single frequency tone, repeated twice in terms of 300 milliseconds on and 10 seconds off.

- 950/333,1400/333,1800/333,0/1000

Indicates repeated playing 333 milliseconds of 950 Hz, 333 milliseconds of 1400 Hz, 333 milliseconds of 1800 Hz, and mute of 1 second.

5.6.6 System time

After login, click **Advanced** > **System time** to open this interface.

Figure 5-18 Clock Service Interface

Basic	ISDN	Routing	Advanced	Security	Call Status	Logs	Tools
System	Media stream	SIP	RADIUS	Tones	<i>System time</i>		

Time zone	(GMT+08:00) Beijing
Current time	2017-05-25 14:19:49 Time synchronization
System time sync interval	120 min
Primary time server	198.60.22.240
Secondary time server	133.100.9.2

Save

Table 5-21 Clock Service Parameters

Name	Description
Time Zone	Select a time zone, the parameter values include: <ul style="list-style-type: none"> • (GMT-11:00) Midway Island • (GMT-10:00) Honolulu, Hawaii • (GMT-09:00) Anchorage, Alaska • (GMT-08:00) Tijuana • (GMT-06:00) Denver • (GMT-06:00) Mexico City • (GMT-05:00) Indianapolis • (GMT-04:00) Glace_Bay • (GMT-04:00) South Georgia • (GMT-03:30) Newfoundland • (GMT-03:00) Buenos Aires • (GMT-02:00) Cape_Verde • (GMT) London • (GMT+01:00) Amsterdam • (GMT+02:00) Cairo • (GMT+02:00) Israel • (GMT+02:00) Zimbabwe • (GMT+03:00) Moscow • (GMT+03:30) Teheran • (GMT+04:00) Muscat • (GMT+04:00) United Arab Emirates • (GMT+04:30) Kabul • (GMT+05:30) Calcutta • (GMT+05:00) Karachi • (GMT+06:00) Almaty • (GMT+07:00) Bangkok • (GMT+07:00) Indonesia • (GMT+08:00) Beijing • (GMT+08:00) Taipei • (GMT+08:00) Singapore • (GMT+08:00) Malaysia • (GMT+09:00) Tokyo • (GMT+10:00) Canberra • (GMT+10:00) Adelaide • (GMT+11:00) Magadan • (GMT+12:00) Auckland
Current time	Display current time for the device. Click Clock calibration to calibrate the time.
System time sync interval	Set the synchronization period of the time. It is 120 minutes by default.
Primary time server	Enter the IP address of preferred time server here. It has no default value.

Name	Description
Secondary time server	Enter the IP address of Secondary time server here. It has no default value.

5.7 Security

5.7.1 Access Security

The administrator is recommended to perform the following operations to prevent mostly illegal accessing to the device:

- Regularly change the admin/operator password for accessing Web GUI
- Regularly change the root/operator password for accessing the device through Telnet/SSH, and improve the password strength
- Regularly change the HTTP/HTTPS/Telnet/SSH port for accessing the device
- Disable Telnet/SSH once accessing is completed.

All of the above are available on **Security>Access** page.

Figure 5-19 Access Configuration Interface

The screenshot shows the 'Access' configuration page under the 'Security' menu. The navigation tabs include Basic, ISDN, Routing, Advanced, Security, Call Status, Logs, and Tools. The 'Access' sub-menu is active, showing options for Access list, Voice security, and Encryption.

Change administrator password

Old password:

New password:

Confirm new password:

Change operator password

New password:

Confirm new password:

Web

HTTPS port: (Range: 1 - 9999, Default: 443)

HTTP port: (Range: 1 - 9999, Default: 80)

Login timeout: s (Range: 60 - 7200)

Telnet& SSH

Telnet: SSH:

Access level:

Ping

Inbound Ping request: Unblock Block

Table 5-22 Access security setting parameters

Name	Description
Change administrator /operator password	Set the administrator/operator password by entering the current password. The password must meet the following requirements: <ul style="list-style-type: none"> ● 8 to 16 characters ● At least two of the following: letters, numbers, and symbols ● Excluding &, =, and “ Please change the initial password at first time login.
Web	
HTTP/HTTPS port	Set the HTTP/HTTPS port for the device. The default value is 80 for HTTP and 443 for HTTPS. HTTP/HTTPS port is use for: <ul style="list-style-type: none"> ● Web accessing (XML command interface) ● Auto Provisioning
Login time out	Set the login timeout interval, the default value is 600s.If you do not operation within timeout interval, you will log out.
Telnet/SSH	
Telnet or SSH	If this parameter is selected, terminals are allowed to access the device through Telnet/SSH. It is not selected by default. When accessing the device through SSH, you should login with user operator , and use su root command to change to user root . Please disable Telnet/SSH in time after accessing is finished.
Telnet port	Set the Telnet port for the device. The default value is 23.
SSH port	Set the SSH port for the device. The default value is 22.
Change Telnet/SSH password	Set password of user root or operator . Password must meet the following requirements: <ul style="list-style-type: none"> ● 6 to 20 characters ● At least the two of following: English letters, numbers, and symbols ● Excluding &, =, and “
Ping	
Inbound Ping request	Block or unblock the Ping requests. The device block the ping requests by default.

5.7.2 Access list

Access list is used to specify the source addresses which are allowed to access the device through Web GUI (HTTP/HTTPS) or Telnet/SSH.


After login, click **Security>Access list** to open the configuration interface.



Note

Once access list is enabled, only addresses specified here are allowed to access the device through Web GUI or SSH.

Figure 5-20 Access list configuration Interface



Step 1 Click **Add**.

Step 2 In the input box, enter IP addresses and select types of service.

Step 3 Select **Enable**, and click **Save**.



Note


- This function takes effect after the system reboots.
- If SSH is selected, please enable SSH on **Security>Access** page.
- The device allows an access list of up to 20 entries.

5.7.3 Voice Security

When the device is deployed in Internet, it is possible to suffer from toll fraud. But you can configure the SIP-allowed IP address for the device to prevent toll fraud.

After login, go to **Security>Voice Security** to set up the SIP-allowed addresses.

Figure 5-21 Voice Security Configuration Interface



- Any: Any IP address is trusted.
- Vary depending on FXO port conneted or not: If there is no E1/T1 connection, any IP address is trusted; otherwise only the listed IP addresses (SIP server, backup SIP server, TLS server, IP addresses included in routing rules, and loopback IP address) are trusted.
- Addresses determined by system: Address for SIP server, backup SIP server, TLS server, IP addresses included in routing rules, and loopback address are trusted.

5.7.4 Encryption

After login, click **Security>Encryption** to open this interface.

Figure 5-22 Encryption Configuration Interface



Table 5-23 Encryption Configuration Parameters

Name	Description
Signal encryption	Choose whether to encrypt signaling. By default, this is not selected.
RTP encryption	Choose whether to encrypt RTP voice pack, the default is 0. <ul style="list-style-type: none"> ● 0: no encryption ● 1: entire message ● 2: header only ● 3: the data body only
T.38 encrypt	Select to encrypt T.38 fax media stream packets. By default, this is not selected.
Encryption method	Set the gateway encryption method, default is 10. The optional parameters as below: <ul style="list-style-type: none"> ● 10: RC4 ● 14: Encrypt14 ● 16: Word reverse(263) ● 17: Word exchange(263) ● 18: Byte reverse(263) ● 19: Byte exchange(263) ● 20: VOS
Encryption key	You may obtain this from service provider

5.8 Call Status

In case of full configurations, the MX100G has one 4T1/E1 card, with four interfaces numbering ISDN1 to ISDN4 from left to right. Users can view the ISDN calling state on the interface in usage. The calling information about ISDN (1) is used as an example.

Click **Call Status > ISDN1** tab to open the interface.

Figure 5-23 ISDN Status Interface

Channel	Call	Direction	Phone No.(This End)	Phone No.(Other End)	Duration	Operation
1	Idle					-
2	Idle					-
3	Idle					-
4	Idle					-
5	Idle					-
6	Idle					-
7	Idle					-
8	Idle					-
9	Idle					-
10	Idle					-
11	Idle					-
12	Idle					-
13	Idle					-
14	Idle					-
15	Idle					-
17	Idle					-
18	Idle					-
19	Idle					-
20	Idle					-
21	Idle					-
22	Idle					-
23	Idle					-
24	Idle					-

Table 5-24 Status Parameters

Name	Description
Call	The call state involves idle, outpulsing, ringing, dialling, initiating a call, ring back, talking, on-hook on the local end, and on-hook on the opposite terminal.

5.9 Log Management

5.9.1 System Status

Critical runtime information of gateways can be obtained in this interface, including:

- The information about login interface (including IP address and permissions of the user)

- SIP registration status
- Call-related signaling and media (RTP) information

Click the label of **Logs> System Status** to open this interface.

Figure 5-24 System Status Interface




Table 5-25 System Status Parameters


Name	Description
Login User Info	<p>Show the IP address and jurisdiction of login user. The numbers following the IP address show the online jurisdiction of the user: 1- administrator; 2 - operator; 3 – viewer. The viewer can only read the configuration, but is not allowed to modify it.</p> <p>When more than one administrator log in at the same time, the first login’s jurisdiction is 1, others are 3; also, when more than one operators log in at the same time, the first one’s jurisdiction is 2, others are 3.</p>
SIP Registration Info	<p>Show registration status:</p> <ul style="list-style-type: none"> ● Not enabled: The registration server’s address is not entered yet; ● Latest response: The latest response message for the registration. 200 means registered successfully; ● No response: No response from registration server. The cause may contribute to 1) incorrect address for the registration server; 2) IP network fault; or, 3) the registration server is not reachable.
Call Context Info	Show the call status.
Rtp Context Info	Show the voice channel related to the calls.

Name	Description
Ann Context Info	Display the playing voice message.

5.9.2 Call Message

Click the label of **Logs > Call Message** to open this interface.

Figure 5-25 Call Message Interface



5.9.3 ISDN Status

Click **Logs > ISDN Status** tab to open this interface.

Figure 5-26 ISDN Status Interface





Table 5-26 ISDN Status Parameters

Name	Description
ISDN Group ID	The ID of an ISDN group.
state	State. <ul style="list-style-type: none"> ● IS indicates the in-service state. ● OOS indicates the out-of-service state. ● MOOS indicates the manually taken-out-of service state, i.e. the backup signaling channel is disabled.
Int Id	The ID of an interface card, which is 0.
side	Two sides of the ISDN: user and network side, which must be set in pairs, with one side being User and the other side being Network.
echo	The echo cancellation function. On: indicates that the echo cancellation is enabled. Off: indicates that the echo cancellation is disabled.
hunting	Two search modes of idle timeslot: <ul style="list-style-type: none"> ● FORWARD ● BACKWARD
DS1	The type of an interface card: T1 or E1. The connection state of the interface card can be: <ul style="list-style-type: none"> ● UP ● DOWN
slot/ds1/ds0	One of interfaces (represented by ds1) on a certain slot (represented by slot) into which the T1 or E1 interface card is inserted. "ds0" specifies a signaling channel. The signaling channel for the E1 card is 16 timeslots and the signaling channel for the T1 card is 24 timeslots.
Equipped MAP	The available state of the remaining 30 timeslots on the E1 card, except timeslots 0 and 16. If the binary value in 0xffffffe is 1, the timeslot is available.
Free MAP	The state of an idle timeslot.
LineType	The frame format, including SF, D4, T1_UNFRAMED, SF, E1, E1_MF, E1_CRC and E1_UNFRAMED.
LineCode	The line code, including B8ZS, AMI, JBZS, HDB3, ZBTSE, B6ZS, JBZS, etc.
LineBuildOut	The line build-out, which is 120 or 75 Ohm.
ClockTiming	The clock source: Local or Through.
Payload	The PCM encoding type: ALAW or ULAW.

5.9.4 System Startup

Click **Logs > System Startup** tab to open this interface. The gateway boot up information is available in this page, including the hardware configuration.

Figure 5-27 System Startup Interface



5.9.5 Manage Log

Click the label of **Logs > Manage Log** to open this interface. Log files can be downloaded through this interface.

Figure 5-28 Manage Log Interface




Table 5-27 Manage Log Parameters

Name	Description
Download log	
Log level	Select the log file level of gateway, default is 4. The higher the level goes, the more details the log file will be. Note: log level should be set to be 4 or lower when gateway is used in normal operation, avoiding influencing the system performance.
Syslog	

Name	Description
System log server	The syslog server receives the logs that are otherwise recorded in debug.log, message.log and boot.log.
Call message server	The syslog server receives the logs that are otherwise recorded in message.log.
Local port for sending logs	The port used to send logs.

Procedure for downloading the log:

Step1 Click **Download**, the gateway begins to assemble the logs.

Step2 After a few seconds, the interface of log saving will appear.

Step3 Click **Save**, and select path to save.


Step4 The user may review the log from the server.

5.10 System Tool

5.10.1 Configuration Maintenance

Click **Tools>Configuration maintenance** to open this interface.

Figure 5-29 Configuration Importing or Exporting Interface



It's allowed to import or export the configuration files through this interface. The exporting procedure is similar to the downloading procedure of log files.

Importing procedure is the same as that of software upgrade.

5.10.2 Upgrade

The device supports two upgrading methods: upgrading by .img file or upgrading by tar.gz file.


If the kernel version is required to upgrade, choose the **.img** file to upgrade, if not, choose the tar.gz file.

Upgrading by .img file

If the kernel version is required to upgrade, choose the **.img** file to upgrade.


Step 1 Click **Tools>Software upgrade>Choose file** to choose an .img file.

Figure 5-30 Upgrade Interface



Step 2 Click **Backup** to save the current configuration.

Figure 5-31 Upgrading interface by .img file



Step 3 Click **Upgrade** and follow the upgrade instructions.

Note: Please contact the supplier to obtain the latest firmware release file.


Upgrading by tar.gz file

The upgrading by tar.gz file will not change the current configurations. But you are advised to backup the configurations by clicking **Export** on **Tools>Configuration maintenance** page before upgrading.

The upgrade procedure is presented as below:

Step 1 Click **Tools>Software upgrade>Choose file** to choose a tar.gz file.

Figure 5-32 Upgrade Interface



Step 2 Click **Upgrade**.

Step 3 Follow prompts to complete the upgrade.



Note

- The device upgrade process may last for several minutes. Do not power off, disconnect (from the network), or restart the device during the process. Otherwise, the system may be damaged, and

the device cannot be started.

- After the upgrade is successful, the device automatically restarts. Access the gateway management system interface again, click **Info** to view and check whether the software version is the upgrade target version.

5.10.3 Restore Factory Settings

Click **Tools**> **Restore factory settings** to restore the parameters of gateway into the factory settings.

The factory settings are designed based on common applications, and therefore, no need to modify them in many deployment situations.

5.10.4 IP Capture

After login, click **Tools** > **IP capture** to open this interface. You are allowed to capture up to three IP voice data files, each with up to 2M bytes. The capture is stored in the downloaded file t1.tar.gz under /log/dump.cap in libpcap format.

Step 1 Go to **System** > **Ethereal capture**, and click **Start**.

Figure 5-33 Ethereal interface



Step 2 Make the problem recur. For example: establish a call.

Step 3 Click **Stop** to finish the capture procedure. A download request window will pop up to allow you to download the captured packets to your PC.

Step 4 If you need help with problem analysis, you can send the captured file to gs@newrocktech.com. You can open the file by using Wireshark.


5.10.5 Reboot

Click **Reboot** on the top right corner to restart the gateway. As this is a system wide reset, it takes longer time.

5.11 Version Information

Click **Info** to view the gateway hardware and software version information.

Figure 5-34 Version Information Interface



5.12 Logout

Click the **Logout** at top right to exit the gateway management system and return to the login interface.